

Local Control Station



Suppression Equipment

General

The Notifier Local Control Station is used for connection to a gas control panel for remote control of the suppression agent isolation and release.

The unit contains a break glass unit for the release, and a push on/push off switch for isolation of the automatic activation of the suppression agent. This will not isolate the manual activation function.

The Local Control Station contains an indicator and a buzzer for confirmation of the isolation.

Both the break glass and switch have flip up safety covers for protection against accidental operation.

On activation of the Local Control Station the switch lamp and buzzer are activated.

If the break glass is activated, the start operation overrides the stop signal from any Local Control Station.

Specifications

Dimensions: 190mm(H) x 110mm(W) x 80mm(D).

Supply Voltage: 24VAC/DC.

Stop Gas Switch: Push On/Push Off with protective flip cover and internal indicator lamp.

Release Break Glass Unit: Yellow break glass with protective flip cover.

Buzzer: 24VDC Pulsing



© 2009 by Honeywell International Inc. All rights reserved.
Unauthorised use of this document is strictly prohibited.

This document is not intended for installation purposes.
We try to keep our product information up-to-date and accurate.
We cannot cover all specific applications or anticipate all requirements.
All specifications are subject to change without notice.

For more information contact your nearest Notifier Sales Office or Distributor
www.notifier.com.au
