



**NOTIFIER**<sup>®</sup>  
by Honeywell

9 Columbia Way  
Baulkham Hills, NSW 2153  
PH 02-9894-1444 • FAX 02-9894-4193  
[www.notifier.com.au](http://www.notifier.com.au)

## ASY-01-043 – Annunciator Name Plate Installation Sheet - Released

20/01/2014 Rev: B

DOC-03-060 ECN14-0004

## 1 Product Overview

This document describes how to install the Annunciator Name Plate.

## 2 Installation

### 2.1 Mounting

1. Open the cabinet inner door.
2. Unscrew the M3 flanged nuts from the mounting studs at the location where the Annunciator Name Plate will be installed.
3. Remove the existing annunciator.
4. Position the Annunciator Name Plate over the mounting studs.
5. Secure the Annunciator Name Plate with the M3 flanged nuts.
6. Fill in the details on the name plate label which can be cut out from page 2 of this document.  
Alternatively this document can be downloaded from the Notifier website ([www.notifier.com.au](http://www.notifier.com.au)) and the text modified.




Figure 1 - Fitting the Annunciator Name Plate

### 3 Label

USE TAB FOR ADJUSTMENT  
FOLD 90° ALONG DOTTED LINE

**BUILDING FIRE SYSTEM**

Z1	ZONE 1
Z2	ZONE 2
Z3	ZONE 3
Z4	ZONE 4
Z5	ZONE 5
Z6	ZONE 6
Z7	ZONE 7
Z8	ZONE 8
Z9	ZONE 9
Z10	ZONE 10
Z11	ZONE 11
Z12	ZONE 12
Z13	ZONE 13
Z14	ZONE 14
Z15	ZONE 15
Z16	ZONE 16

Figure 2 - Default Label



USE TAB FOR ADJUSTMENT  
FOLD 90° ALONG DOTTED LINE

Figure 3 - Blank Label

